

Proper Installation of 1964-65 Convertible Top Boot Clips

1. Slide the bottom half of the clip into the pre-cut slots along the edge of the boot, lining up the holes between boot and clip.

Pop-Rivet Gun

2. Use a pop-rivet to fasten the bottom section of the clip in place.

3. Slide the upper half of the clip into the slots on the lower half.

4. Push forward until both halves lock together.

