



Installation

Clean glass thoroughly.

Apply gasket onto glass starting at the corners. Make sure corners are aligned properly. For gaskets without corners, make sure you place the vulcanized seam in the bottom middle of the glass.

Insert a 1/4" rope in the section at the bottom of the gasket. Starting at the bottom and overlapping 6 to 8 inches.

Spray the gasket a soapy water solution to help ease the installation.

If the chrome trim for your application attaches with clips that mount to the pinch weld underneath the rubber seal please install the clips now.

Lay the glass and gasket into the vehicle opening making sure it is aligned squarely.

Start pulling the rope from the inside of the vehicle working slowly across the bottom and up the sides and finally across the top. Gently pat the glass into place with a flat hand from the outside.

Complete the installation by inserting the edge of the rigid molding into the clip until it snaps into place.

Note: Windshield installations after 1978 should be sealed with a urethane adhesive.
Follow the urethane adhesives manufacturer's installation procedures.